

## OPERATING MANUAL EN

## SF SERIES STEP IMPULSE SEALER



- Read this manual carefully prior to use.
- Technology is subject to change without further notice.

**1. Operation method:**

Supply the 220V power,turn on the swith,power pilot lamp light,then according to the thickness of the plastic film adjusting the sealing time,now the machine are ready to work.

Step the pedel plate of the machen,wait 2 sec after the working pilot lamp off.Loss the pedel plat.

That is all



**2. Announcements:**

This product is eletronic machinery,please take care about the moisture-proof,and the power voltage should be AC220V

Please do not use this machine for the sealing of combustibile or explosive stuff.

**3. Specification:**

Model	SF-400	SF-600	SF-800	SF-1000
Impulse power	500W	750W	850W	1000W
Sealing Length	40	60	80	100
Heating Time	0.2-2S	0.2-2S	0.2-2S	0.2-2S
Weight	14Kg	16Kg	20Kg	22Kg

**Packing List:**

Name	Machine Head	I Type Frame	Transome For Frame	Transome For pedel plat	pillot For pedel plat	Screw	Spare Parts
Unit	PC	PC	PC	PC	PC	Bag	Set
Number	1	2	1	2	1	1	1